


## Clamp Assembly



Item	Qty.	Part Number / Description
1	1	PIM-10235 Clamping plate guide
2	1	PIM-10236 Clamp lead screw
3	2	PIM-10237 Screw connecting block
4	2	PIM-10238 Clamp plate
5	6	3/8-16 Hex nut
6	1	PIM-10239 Clamp handle
7	1	PIM-10240 Washer
9	1	PIM-10242 Clamping block
10	2	Hex head screw 3/8-16 x 2.50
11	4	Hex head screw 3/8-16 x 1.25
12	2	3/8" Lock washer
13	1	3/16" x 7/8" rollpin
14	1	Snap ring